

Cavex Temporary Cement Handling

1. Mix equal lengths of catalyst and base paste.



2. Apply the mixed cement onto the temporary crown or bridge and place it on the preparation.

